

October 3, 2006

Eton "FR" emergency crank radio series phone tip compatibility: arranged by tip style, brand and model

If your tip style doesn't appear here, call Eton Corporation and ask for Technical Support: 1-800-872-2228

U.S., 1-800-637-1648 Canada.

<i>TIP STYLE A</i>	QCP2035	2285	5190
<u>AUDIOVOX</u>	QCP2035A	2300	5210
CDM8400	<u>LG</u>	252	5300
CDM8410	PM225	2600	5510
CDM8450	<u>MOTOROLA</u>	2650	6010
CDM8610VM	G520	282	6015
CDM8615CS	i500	3100	6015i
CDM8900	i550	3105	6016i
CDM8910BM	i700	3108	6020
CDM8910VM	<u>SAMSUNG</u>	3120	6100
CDM8910VW	MM-A700	3200	6101(CLASSIC)
CDM8940VW	SPH-A460	3205	6101 via Nokia CA-44
CDM9900	SPH-A470	3210	adapter
CDM9950	SPH-A500	3220	6103 via Nokia CA-44
PDM8920	SPH-A560	3230	adapter
<u>KYOCERA</u>	SPH-A600	3285	6108
1135	SPH-A620	3300	6120
1155	SPH-A660	3310	6160
2119	SPH-A760	3315	6161
2119b	SPH-A880	3330	6162
2135	SPH-IVI660	3350	6170
2235	SPH-N240	3360	6185i
2255	SPH-N270	3361	6190
2325	SPH-N400	3390	6200
2345	VGA-1000	3395	6210
3225	VM-A680	3410	6220
3245	<u>SANYO</u>	3510	6225
3250	PM-8200	3510i	6230
7135	SprintModelIRL2500	3520	6230i
BLADE	SprintModelIRL4920	3530	6236i
K10 ROYALE	SprintModelSCP5500	3560	6250
K110	SprintModelSCP7300	3570	6255i
K112	SprintModelSCP8100	3585	6260
K7RAVE	SprintModelSCP8200	3585i	6310
K9RAVE	SprintModelVM4500	3586	6310i
KE413	<u>TOSHIBA</u>	3586i	6340
KE413C	CDM9950SP	3587i	6340i
KE414	VM4050	3588i	6360
KE414C		3589i	6370
KE423	<i>TIP STYLE B</i>	3590	6385
KE423C	<u>NOKIA</u>	3595	640
KE424	1100	3600	650
KE424C	1108	3610	6510
KE433	1221	3620	6560
KE433C	1260	3650	6585
KE434	1261	3660	6590
KE434C	2100	5100	6590i
KX413	2112	5120	6600
KX414	2115i	5125	6610
KX424	2128i	5140	6610i
KX433	2260	5160	6620
KX434	2270	5165	6630
PHANTOM	2275	5170i	6650
QCP2027	2280	5185i	6651

6670
6680
6681
6800
6810
6820
6822
7110
7160
7190
7200
7210
7250
7250i
7260
7270
7280
7600
7610
7650
7710
8210
8250
8260
8265
8265i
8270
8280
8290
8310
8390
8801
8810
8850
8850Gold
8855
8860
8890
8910
8910i
9200
9210i
9290
9300
9500
N-Gage
N-GageQD
THR850
THR880

TIP STYLE C

SAMSUNG

IP-A790
SCH-A210
SCH-A310
SCH-A399
SCH-A475
SCH-A505
SCH-A509
SCH-A530
SCH-A539
SCH-A561
SCH-A563

SCH-A564
SCH-A591
SCH-A592
SCH-A595
SCH-A599
SCH-A610
SCH-A650
SCH-A670
SCH-A720
SCH-A809
SCH-A890
SCH-N181
SCH-N182
SCH-N191
SCH-N195
SCH-N330
SCH-N370
SCH-N375
SCH-X199
SCH-X209
SCH-X219
SCH-X309
SCH-X319
SCH-X359
SGH-A200
SGH-A288
SGH-A300
SGH-A308
SGH-A400
SGH-A408
SGH-A500
SGH-A608
SGH-A800
SGH-C100
SGH-C207
SGH-C225
SGH-D100
SGH-D410
SGH-D415
SGH-D500
SGH-D500C
SGH-D508
SGH-D600
SGH-E100
SGH-E105
SGH-E315
SGH-E316
SGH-E317
SGH-E330
SGH-E335
SGH-E400
SGH-E700
SGH-E715
SGH-E730
SGH-K258
SGH-N200
SGH-N288
SGH-N400
SGH-N500
SGH-N620
SGH-N625
SGH-N626

SGH-N628
SGH-N635
SGH-P107
SGH-P207
SGH-P408
SGH-P735
SGH-Q200
SGH-Q208
SGH-Q300
SGH-R200
SGH-R208
SGH-R210
SGH-R220
SGH-R225
SGH-R225m
SGH-S307
SGH-T100
SGH-T108
SGH-T200
SGH-T208
SGH-T400
SGH-T408
SGH-T410
SGH-T500
SGH-V200
SGH-V205
SGH-V206
SGH-X100
SGH-X105
SGH-X425
SGH-X426
SGH-X427
SGH-X427m
SGH-X475
SGH-X495
SGH-X497
SGH-X600
SPH-A790

TIP STYLE D

LG
4020
A7110
C1500
C2000
E7200
F9100
F9200
G4010
G4011
G4015
G4050
L1150
L1200
L1400
LX5450
LX5550
VI-5225
VX4500
VX4600
VX6000

TIP STYLE E
SIEMENS

A52
A55
A56
A57
A60
A65
C55
C56
C60
C61
C62
C65
CF62
CFX65
CT56
CT66
CX65
M55
M56
M65
MC60
S55
S56
S57
S65
SF65
SK65
SL55
SL56
SL65
SL65ESCADA
SX1

TIP STYLE F

SONY/ERCSSN

AKONO K500i
A2218z
F500i
J200c
J210c
J300c
K300c
K300i
K500c
K500i
K506c
K508c
K600i
K608i
K700c
K700i
P800
P802
P900
P908
P910a
P910c
P910i
R300

R380WORLD
S700c
S700i
S710a
T100
T105
T106
T200
T226
T230
T237
T237s
T28WORLD
T28z
T290c
T300
T306
T310
T316
T39
T39m
T60
T606
T608
T60i
T600
T61
T610
T616
T61c
T61d
T61LX
T61z
T62U
T628
T630
T637
T68
T68i
T68ie
T68m
V600i
V800
Z1010
Z200
Z208
Z500a
Z502a
Z600
Z608
Z800i

TIP STYLE G
MOTOROLA

388c
A1000
A630
A760
A830
A835
A840
A845
A860

A920
A925
C331
C332
C333
C341
C343
C343c
C353
E310
E380
i30sx
i35s
i50sx
i55sr
i55sx
i58sr
i80s
i85s
i88s
i90c
i90cse
i95cl
iM1000
MPx220
T300p
T720
T720i
T721
T722
T722i
T725
T725G
T730
T731
Timeport270c
TimeportP280
V120
V120c
V120e
V120t
V120x
V200
V260
V262
V265
V276
V300
V330
V400
V500
V535
V505
V551
V60
V600
V60c
V60g
V60i
V60p
V60s
V60t

V60tColor
V60x
V65p
V65s
V66
V70
V710
V810
V980

TIP STYLE H
MOTOROLA

I205
I530
I560
I605
I710
I730
I760
I830
I835
I836
I860

TIP STYLE J
MOTOROLA

A1200
A668
A70
A732
A780
C305
C362
C363
E610
E615
E680
E680i
E685
L2
L6
SLVR L7
M300
PEBL
V190
V191
V195
V235
V320
V323
V325
V360
V361
V660
KRZR
Motorola Q
RAZR V3

TIP STYLE K
LG

VX10
VX3100
VX4400

TIP STYLE L
LG

AX4650
AX4750
AX5000
FUSIC
LX325
LX350
Migo
MM-535
PM325
VX3200
VX3300
VX3450
VX4400
VX4700
VX5200
VX5450
VX5550
VX6100
VX7000
VX8000
VX8100
VX8300
VX9800

TIP STYLE M
PALM TREO 600

TIP STYLE N
PALM TREO 650, 700

TIP STYLE O
BLACKBERRY USB

TIP STYLE P
BLACKBERRY FLAT